
LIGHTING SYSTEM

PRECAUTION

1. PRECAUTION OF HEADLIGHT BULB REPLACEMENT

- (a) If the surface halogen light (headlight) is coated with oil, light service life is shortened because of the heat generated when the light is on.
- (b) Since the internal pressure of the halogen light bulb (headlight) is high, handle carefully. It may explode if dropped.
- (c) Try not to handle the lens too much when changing the light because it could result in a dirty or moist lens. Always have the replacement bulb prepared before starting the installation.
- (d) Always replace the bulb with one of the same wattage.
- (e) In order to avoid a cloudy lens or leakage, firmly reinstall the socket after bulb replacement.



PARTS LOCATION





