

BODY

GENERAL MAINTENANCE

1. TIGHTEN BOLTS AND NUTS

- (a) Tighten the bolts and nuts on the chassis parts listed below, if necessary.
 - Front axle and suspension
 - Drive train
 - Rear axle and suspension
 - Brake system
 - Engine mounting
 - Other chassis parts
- (b) Tighten the bolts and nuts on the body parts listed below, if necessary.
 - Seat belt system
 - Seats
 - Doors and hood
 - Body mountings
 - Fuel tank
 - Exhaust pipe system
 - Other body parts

2. CLEAN AIR CONDITIONING FILTER

- (a) Visually inspect the surface of the filter.
- (b) If the filter is contaminated with foreign matter, clean or replace the filter.